



# Home Automation

---

## On Google Assistant:

*Startup (say):* Talk to YY Home Automation

*Command (say):* [action] [device] or [device] [action]

## Actions :

On / Off :

Alarm [alarm], Basement Entry Lights [basement], Back Door Camera [back camera], Garage Camera [garage camera], Kitchen Lights [kitchen lights], Living Room Lights [living room], Front Chandelier Lights [foyer], Library Desk Light [library], Family Room Post Lights [family room], Master Bed Room Post Lights [master bedroom], Kitchen Counter LED Strip Lights [kitchen counter ], Outside Colour LED Strip Lights [outside], Laundry Room LED Strip Lights [laundry], Back Yard Lights [back yard], Lawn Watering System [lawn].

Arm/Disarm :

Home Automation System [home automation], Security System [security], Emergency Alert System [emergency alert], Front Door Camera [front camera], Back Door Camera [back camera], Garage Camera [garage camera], Inside Camera [inside camera], Outside Camera [outside camera].

Open / Close :

Left Garage Door [left garage], Right Garage Door [right garage].

Temperature :

Laundry Room [laundry], Family Room [family room], Basement [basement],  
Garage [garage], Home [house], Outside [outside].

Status :

Back Door [back door], Front Door [front door], Basement Windows [basement windows], Left Garage Door [left garage], Right Garage Door [right garage], Both Garage Doors (Garage Doors) [garage doors] , Foyer (Front Door) Zone [foyer], Basement Entry Zone [basement], Kitchen (back door) Zone [kitchen], Garage Zone [garage], Laundry Zone [laundry], Back Yard Zone [back yard], Security System [security], Emergency Alert System [emergency alert], Home Automation System [home automation], Front Camera [front camera], Back Camera [back camera], Basement Camera [basement camera], Foyer Camera [foyer camera], Garage Camera [garage camera], Inside Camera [inside camera], Laundry Camera [laundry camera], Living Room Camera [living room camera], Master Camera [master camera], Outside Camera [outside camera], Upstairs Camera [upstairs camera], Cameras, Windows, Doors, Home, Home Automation, Enable, Environmental, Doorbell, Lights, Entry Cameras, Uptime, Lawn .

Set :

Good Morning [morning], Good Night [night], Vacation [vacation], Movie Time [movie], Movie Finish, TV Time [tv], TV Finish, Leave Home [leave], Arrival Home [arrival].

Details / Reset :

Security System [security], Emergency Alert System [emergency alert],  
Doorbell, Entry Cameras, Room Temperature, Lights.

Enable/Disable :

Home Automation System [home automation], Security System [security],  
Emergency Alert System [emergency alert], Front Door Camera [front camera], Back Door Camera [back camera], Garage Camera [garage camera], Inside Camera [inside camera], Outside Camera [outside camera], Entry Camera [entry camera], Day, Night, Away], Doorbell, Lights.